

HESAI

www.hesaitech.com

AT360

Hybrid Solid-State Lidar User Manual

Classification: CO (Public)

Doc version: A04-en-250810

Table of Contents

■ About this manual	1
Access to this manual	1
Technical support	1
Legends and format	1
■ Safety notice	2
Special warnings	2
Operating environment	3
Personnel	5
Installation and operation	5
Repair	9
1. Introduction	10
1.1. Operating principle	10
1.2. Basic structure	11
1.3. Channel distribution	12
1.4. Specifications	13
2. Setup	16
2.1. Mechanical installation	16
2.2. Electrical interface	18
2.2.1. Connector use	18
2.2.2. Cable (Ethernet)	21
2.3. Connection box (optional)	22
2.3.1. Connection	25
2.4. Network settings on the host computer	27
2.4.1. In Windows	28
2.4.2. In Ubuntu	31

2.5. Tools	34
3. Data structure	35
3.1. Point Cloud Data Packet	36
3.1.1. Ethernet Header	36
3.1.2. UDP data	37
3.1.3. Ethernet tail	43
3.1.4. Point cloud data analysis method	43
4. Maintenance	44
Appendix A: Channel distribution data	46
A.1. Angular position and performance	46
A.2. Angle correction file	65
A.3. Angle correction calculation	70
A.3.1. Horizontal angle of the current firing channel	70
A.3.2. Vertical angle of the current firing channel	71
Appendix B: Nonlinear reflectivity mapping	72
Appendix C: Legal notice	75

■ About this manual

Please make sure to read through this user manual before your first use and follow the instructions herein when you operate the product. Failure to comply with the instructions may result in product damage, property loss, personal injuries, and/or a breach of warranty.

Access to this manual

To obtain the latest version, please do one of the following:

- Contact your sales representative of Hesai.
- Contact Hesai technical support at service@hesaitech.com.

Technical support

If your question is not addressed in this user manual, please contact us at:

- service@hesaitech.com
- <https://www.hesaitech.com/technical-support/>
- <https://github.com/HesaiTechnology>

Legends and format



Warnings: Instructions that must be followed to ensure safe and proper use of the product.



Notes: Additional information that may be helpful.

Names of data fields are in monospace font.


For example: **Distance** represents the Distance field.

■ Safety notice

- Please make sure to read through this safety notice and follow all the instructions and warnings. Failure to comply with the instructions and warnings may result in product damage, property loss, and/or personal injuries.
- Please check the certification information on the product's nameplate. If an agreement has been made not to present certification information on the nameplate, please follow the agreed-to arrangements.
- If you incorporate this lidar product into your product(s), you are required to provide this user manual (or access to this user manual) to the intended users of your product(s).
- This lidar product is intended as a component of an end product. The end-product supplier is responsible for assessing the risk of use in accordance with applicable standards and informing the intended user of safety-related information.
- Should there be other agreements with specific users, the other agreements shall apply.
- Before using a product, please confirm with Hesai the development maturity of the product in a timely manner. For products still in development, Hesai makes no warranty of non-infringement nor assumes any responsibility for quality assurance.

Special warnings

Laser safety



Hot surface



Hot parts!

Burned fingers when handling the parts.

Wait one-half hour after switching off before handling the parts.

Abnormalities

In any of the circumstances listed below, stop using the product immediately:

- If you suspect malfunctions of or damage to the product, with symptoms such as significant noise or visible vibration.
- If you or people in the nearby environment feel discomfort.
- If any device or equipment in the nearby environment malfunctions.

Meanwhile, contact Hesai or an authorized Hesai service provider for more information on product disposal.

Prohibition of disassembly

Unless expressly agreed to in writing by Hesai, do NOT disassemble the product.

Operating environment

Radio frequency (RF) interference

- Before using the product, make sure to read all the signs and notices on the product enclosure (including the nameplate). If specific users require not presenting certification information on the nameplate, please follow the agreed-to arrangements.
- Although the product is designed, tested, and manufactured to comply with the regulations on RF radiation (such as FCC, CE-EMC, or KCC), the radiation from the product may still influence electronic devices.

Vibration

- If significant mechanical shocks and vibration exist in the product's operating environment, please contact Hesai's technical support to obtain the shock and vibration limits of your product model. Exposure to over-the-limit shocks or vibration may damage the product.
- Make sure to package the product in shock-proof materials to avoid damage during transport.

Explosive atmosphere and other air conditions

- Do NOT use the product in any area where a potentially explosive atmosphere is present, such as where the air contains high concentrations of flammable chemicals, vapors, or particulates (including particles, dust, and metal powder).
- Do NOT expose the product to environments that have high concentrations of industrial chemicals, including liquefied gases that are easily vaporized (such as helium). Such exposure can damage or impair product functionality.

Chemical environment

Do NOT expose the product to corrosive or strong polar chemical environments (such as liquids or gases), including but not limited to strong acids, strong bases, esters, and ethers. This is to avoid damage to the product (including but not limited to water resistance failure).

Ingress protection (IP)

Please check the product's user manual for its IP rating (refer to [Section 1.4 Specifications](#)). Make sure to avoid any ingress beyond that rating.

Operating temperature

Please check the product's user manual for its operating temperature (refer to [Section 1.4 Specifications](#)). Make sure not to exceed the operating temperature range.

Recommended storage conditions

Please store the product in a dry and well-ventilated place. The recommended ambient temperature is $23 \pm 5^{\circ}\text{C}$, and the humidity is between 30% and 70% RH.

Light interference

Certain precision optical instruments may interfere with the laser light emitted from the product. Please check all the instructions for these instruments and take preventive measures if necessary. For example, protective leather covers are provided for certain product models; when these lidars are temporarily not used for measurement, the leather covers can be applied to block laser light emission.

Personnel

Recommended operator qualifications

The product should be operated by professionals with engineering backgrounds or experience in operating optical, electrical, and mechanical instruments. Please follow the instructions in this manual when operating the product and contact Hesai technical support if needed.

Medical device interference

- Some components in the product can emit electromagnetic fields. If the product operators or people in the nearby environment wear medical devices (such as cochlear implants, implanted pacemakers, and defibrillators), make sure to consult the physicians and medical device manufacturers for medical advice, such as determining whether keeping the product a safe distance away from the medical devices is needed.
- If you suspect that the product is interfering with your medical device, stop using the product immediately.

Installation and operation

Power supply

- Before powering on the product, make sure the electrical interfaces are dry and clean. Do NOT power on the product in humid conditions.
- Do NOT use out-of-spec or damaged cables or adapters.
- You are recommended to use only the cables and power adapters provided by Hesai. If you are to design, configure, or select the power supply system (including cables) for the product, make sure to comply with the electrical specifications in the product's user manual (refer to [Section 1.4 Specifications](#) and the Power Supply Requirements section if available); for technical support, please contact Hesai.
- Please check [Section 2.2 Electrical interface](#) and strictly follow the instructions on plugging/unplugging the connector. If abnormalities already exist (such as bent pins, broken cables, and loose screws), stop using the product and contact Hesai technical support.

Eye safety

The product is a Class 1 laser product. It satisfies the requirements of:

- IEC 60825-1:2014
- EN 60825-1:2014+A11:2021
- 21 CFR 1040.10 and 1040.11 except for deviations (IEC 60825-1 Ed.3) pursuant to Laser Notice No.56, dated May 8, 2019.

CAUTION: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION

- For maximum self-protection, it is strongly warned that users do NOT look into the transmitting laser through a magnifying product (microscope, eye loupe, magnifying glass, etc.).
- This product does not have a power switch. It starts operating once connected to power. During operation, the entire optical window can be regarded as the product's laser emitting window; looking at the optical window can be regarded as looking into transmitting laser.

Product enclosure

- Do NOT squeeze or pierce the product. If the product enclosure is broken, stop using it immediately and contact Hesai technical support.
- Certain product models contain high-speed rotating parts. To avoid potential injuries, do NOT operate the product if the enclosure is loose.
- If the product enclosure consists of fins or grooves, please wear gloves when handling the product. Applying too much pressure with your bare hands may cause cuts, bruises or other injuries.

Drops and burns

The product contains metal, glass, and plastic, as well as sensitive electronic components. If the product is dropped or burnt, stop using it immediately and contact Hesai technical support.

Optical window



The location of the optical window is illustrated in [Section 1 Introduction](#).

- Do NOT apply protective film, wax or any other substance on the optical window.
- To keep the product's optical window from fingerprints and other stains, do NOT touch the optical window with bare hands. If the optical window is already stained, please refer to the cleaning method in [Section 4 Maintenance](#).
- To prevent scratches, do NOT touch the product's optical window with hard or sharp objects. If scratches already exist, stop using the product and contact Hesai technical support. Severe scratches may affect the quality of the product's point cloud data.

Mounting

- Before operating the product, make sure it is properly and securely mounted. The mounting should prevent the product from leaving its mounting position under external forces (such as collisions, high winds, and stone impacts).
- Before installing any exterior part, please ensure that each exterior part and its movable area do not overlap the Field of View (FOV) of the lidar.



The FOV of lidar is the spatial angular range bounded by the horizontal and vertical FOV ranges (see [Section 1.4 Specifications](#)); the distance to the origin of the lidar's coordinate system is not limited. For inquiries about the FOV, please contact Hesai technical support.

Hot surface

During operation or the time period after the operation, the product's enclosure can be hot.

- To prevent discomfort or even burns, do NOT touch the product's enclosure with your skin.
- To prevent fires, make sure to keep flammable materials away from the product's enclosure.

Certain product models support active heating of the optical window to reduce the impact of ice and frost.

- While active heating is ON, the optical window can be hot. To prevent discomfort or even burns, avoid direct skin contact with the optical window.
- When the optical window is free of ice and frost, you may turn off active heating.

Peripherals

The product may be used along with accessories and devices, such as suction cup mounts, extension cables, power supplies, network devices, GNSS/PTP devices, CAN transceivers, and cleaning equipment.

When selecting a peripheral, please refer to all relevant specifications in the product's user manual or contact Hesai technical support. Using out-of-spec or unsuitable devices may result in product damage or even personal injuries.

Firmware and software upgrading

Make sure to use only the upgrade files provided by Hesai. Make sure to observe all the instructions provided for that upgrade file.

Customized firmware and software

- Before using a customized version of firmware and software, please fully understand the differences in functions and performance between the customized version and the standard version.
- Make sure to strictly follow all the instructions and safety precautions provided for that customized version. If the product does not function as anticipated, stop using the product immediately and contact Hesai technical support.

Point cloud data processing

- Certain product models support one or more point cloud data processing functions, including but not limited to: Noise Filtering, Interstitial Points Filtering, Retro Multi-Reflection Filtering, and Non-Linear Reflectivity Mapping.
- These functions are configurable and are intended only to assist the user in extracting information from the point cloud data. Users are in full control of whether to use any of these functions. Moreover, users are responsible for analyzing the product's intended application scenarios and evaluating the risk of enabling one or more of these functions in combination.
- To learn about the supported functions of a product model, please contact Hesai technical support.

Repair

- Unless expressly agreed to in writing by Hesai, do NOT disassemble, repair, modify, or retrofit the product by yourself or entrust any third party to do so. Such a breach:
 - can result in product damage (including but not limited to water resistance failure), property loss, and/or injuries;
 - shall constitute a breach of warranty.
- For more product repair issues, please contact Hesai or an authorized Hesai service provider.

1. Introduction

1.1. Operating principle

Distance measurement: Time of Flight (ToF)

1. A laser diode emits a beam of ultrashort laser pulses onto the target object.
2. The laser pulses are reflected after hitting the target object. The returning beam is detected by an optical sensor.
3. Distance to the object can be accurately measured by calculating the time between laser emission and receipt.

$$d = \frac{ct}{2}$$

d: Distance

c: Speed of light

t: Travel time of the laser beam

1.2. Basic structure




Figure 1. Front view




Figure 2. Coordinate system (isometric view)




Figure 3. Mirror rotation direction (top view)

The lidar's coordinate system is illustrated in [Figure 2](#).

- Z-axis is the axis of rotation.
- The origin's exact position is shown in [Figure 5](#). All measurements are relative to the origin.

A rotating mirror is used for horizontal scanning, shown as the dotted box in [Figure 3](#).

The lidar's azimuthal position (i.e., azimuth of the current firing channel) is defined in [Figure 3](#).

- The mirror rotates clockwise in the top view.
- Y-axis corresponds to 0°.

1.3. Channel distribution

As shown in [Figure 4](#) and detailed in [Appendix A Channel distribution data](#), the laser channels are almost evenly distributed. The designed vertical resolution is 0.05° in the central FOV and slightly larger in the margins.




Figure 4. Channel vertical distribution




Figure 5. Origin of coordinates (unit: mm)

Each channel has an intrinsic angle offset, both horizontally and vertically. The offset angles are recorded in this lidar unit's angle correction file (see [Section A.2 Angle correction file](#)).

1.4. Specifications

SENSOR

Scanning method	1-D rotating mirror (hybrid solid-state)
Number of channels	360 (300 enabled)
Ranging capability	250 m (at 10% reflectivity)
Ranging accuracy	± 5 cm (typical)
Ranging precision	3 cm (typical, 1σ)
FOV (H $\times$ V) ①	$120^\circ \times 18^\circ$ (-9° to $+9^\circ$)
ROI (H $\times$ V) ①	$35^\circ \times 12^\circ$ (-6° to $+6^\circ$)
Resolution (H $\times$ V)	ROI: $0.06^\circ \times 0.05^\circ$ Non-ROI: $0.12^\circ \times 0.10^\circ$
Frame rate	10 Hz
Return mode	Dual Return: First and Strongest

MECHANICAL/ELECTRICAL/OPERATIONAL

Wavelength	905 nm
Laser class	Class 1 Eye Safe
Ingress protection	IP6K7 & IP6K9K
Dimensions	$158 \times 119 \times 52$ (WDH, mm)
Rated voltage range ②	DC 9 to 16 V
Power consumption ③	16 W
Operating temperature	-40°C to 85°C

Storage temperature	-40°C to 105°C
Weight	1080 g

DATA I/O

Data transmission	Automotive Ethernet, 1000BASE-T1, slave mode
Measurements	Distance, azimuth angle, and reflectivity
Valid point rate ④	5 700 000 points/sec
Point cloud data rate ⑤	233/672 Mbps (avg/peak)
Clock source	PTP (802.1AS AUTOSAR)
PTP clock accuracy	$\leq 1 \mu\text{s}$
PTP clock drift ⑥	$\leq 5 \mu\text{s/s}$



Specifications are subject to change. Please refer to the latest version of this manual.

Notes to specifications

- | | |
|--------------------------------|---|
| ① FOV and ROI | Horizontally symmetric with respect to the 90° azimuthal position (i.e. the X-axis, as shown in Figure 3) |
| ② Rated voltage range | Nominal voltage: 12 V |
| ③ Power consumption | <ul style="list-style-type: none">• Typical value, not including accessories such as the connection box.• The external power supply should be able to provide at least 40 W. |
| ④ Valid point rate | Defined as the point cloud data points (number of returns) generated per second. |
| ⑤ Point cloud data rate | Considering the duty cycle for point cloud data transmission and the FOV's ROI design, the peak data rate is higher than the average data rate. |
| ⑥ PTP clock drift | Defined as the drift at a constant temperature after the lidar (slave clock) loses connection to the PTP master. |

2. Setup

Before operating the lidar, strip away the transparent protective film on the optical window.



The information in this section may be different for customized models. The mechanical drawings and data exclusively provided for customized models shall prevail.

2.1. Mechanical installation




Figure 6. Right side view (unit: mm)




Figure 7. Front view (unit: mm)




Figure 8. Bottom view (unit: mm)

2.2. Electrical interface

2.2.1. Connector use

TE connector part number: 2413280-1 (male socket, on the lidar)




Figure 9. Connectors



- Before connection, check the pins on the socket and the holes on the plug. In case of bent pins or damaged holes, stop using the connector and contact technical support.
- To prevent breakdowns, turn off the power source before connection and disconnection.
- Do NOT attempt to force open a connection by pulling on the cables or by twisting the connectors in any way. Doing so can loosen the connectors' shells, or even damage the contacts.
- If the connector's shell is accidentally pulled off, stop using the connector and contact Hesai technical support.
- Do NOT attempt to assemble the connector's shell and cable collet; do NOT connect a connector without its shell. Doing so may damage the lidar's circuits.
- For further troubleshooting, please contact Hesai technical support or obtain work instructions from the connector manufacturer.
- The connector is designed to withstand at least 20 mating cycles; exceeding this number may increase the risk of connector damage.

Connection	1. Turn off the power source. 2. Make sure the plug's red CPA is on the same side as the socket's locking nose. 3. Push the plug straight into the socket until you feel and hear a click. 4. Push the red CPA towards the socket until you feel and hear a click.
Disconnection	1. Turn off the power source. 2. Pull the red CPA away from the socket until you feel and hear a click. 3. Depress the black locking latch; then pull the plug from the socket.




Figure 10. Connection




Figure 11. Disconnection




Figure 12. Locking latch

2.2.2. Cable (Ethernet)

Outer diameter (OD) = 4.10 ± 0.20 mm

Minimum bend radius:

- Single: $5 \times \text{OD}$
- Multiple: $15 \times \text{OD}$

2.3. Connection box (optional)

Users may connect the lidar with or without a connection box.




Figure 13. Connection box (unit: mm)

An additional cable assembly is used for connecting the lidar (on the left) and the connection box (on the right), as shown below.



One cable's head cannot connect to another cable's tail, so each lidar can only use one cable.




Figure 14. Cable assembly between lidar and connection box (unit: mm)

The wire colors and cross-section areas are listed below.

Pin No. on CNT1	Pin No. on CNT3	Signal	Wire color	Wire cross section
1	4	VCC	Red	0.75 mm ²
2	5	Reserved	Green	0.35 mm ²
3	2	Reserved	White	0.35 mm ²
4	8	GND	Black	0.75 mm ²
5	7	Reserved	Black	0.35 mm ²
6	6	Reserved	Yellow	0.35 mm ²
Pin No. on CNT1	Pin No. on CNT2	Signal	Wire color	Wire cross section
D2	1	MDI-P	White	-
D1	2	MDI-N	Green	-




Figure 15. Connection box (front)

Port number	Port name	Description
A	Reserved port	Do NOT connect this port to external signals.
B	Power port	Use a DC-005 power socket (outer diameter: 5.5 mm; inner diameter: 2.1 mm).
C	Standard Ethernet port	RJ45, 1000 Mbps Ethernet




Figure 16. Connection box (back)

Port number	Port name	Description
D	Reserved port	Do NOT toggle or connect the DIP switches.
E	Power output port	See CNT3 in Figure 14 ; part number: 2311621-1
F	Automotive Ethernet port	See CNT2 in Figure 14 ; part number: 2304372-1

2.3.1. Connection




Figure 17. Connection with PTP (software simulation)




Figure 18. Connection with PTP (hardware device)

2.4. Network settings on the host computer

The lidar has no power switch. It starts transmitting data when both of these conditions are met:



- The lidar is connected to power.
- The lidar is connected to a host computer via Ethernet.

To analyze point cloud data, configure the network parameters of the host computer:



Network parameters	Value	Description
IP address	192.168.1.X	X can be selected from 2 to 200 and from 202 to 254.
Subnet mask	255.255.255.0	-
VLAN ID	Range: 1 to 4094	Required only when VLAN tagging is used. Make sure the host computer and the lidar use the same VLAN ID.

2.4.1. In Windows

1. [**Control Panel**] > [**Network and Internet**] > [**Network and Sharing Center**] > [**Change adapter settings**].
2. Right-click [**Ethernet**] or [**Ethernet X**] which shows Ethernet connection (with no red cross at the bottom left of the icon) > Select [**Properties**].



3. Double-click [**Internet Protocol Version 4 (TCP/IPv4)**].
4. Select [**Use the following IP addresses**] > Input the host computers's IP address and subnet mask.




Ping command can be used to check the connection:



1. Press Win + R to open the Run dialog box.
2. Enter "cmd" and click [**OK**] to open the Command Prompt.
3. Enter "ping 192.168.1.201" and check the output.

5. To enable VLAN tagging:

Click [**Configure**] > Under the [**Advanced**] tag, select [**VLAN ID**] from the [**Property**] list > Input a VLAN ID in the [**Value**] box > Click [**OK**].



If the [**Property**] list has no [**VLAN ID**], it is recommended to update the network adapter driver.

2.4.2. In Ubuntu

1. Find the host computer's network interface name.

Method 1

- a. Open **Settings — Network**.
- b. Look for the interface whose status is "Connected".
The name in parentheses after "Ethernet" is the network interface name.



Method 2

- a. Open a terminal and run this command:

```
ifconfig
```

- b. Look for the interface with non-zero RX packets and bytes.
(In the example below, **enp5s0** shows non-zero Rx packets and bytes, indicating active data transmission.)

```
> ifconfig
docker0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    inet [REDACTED] netmask [REDACTED] broadcast [REDACTED]
    ether [REDACTED] txqueuelen 0 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

enp2s0f0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    ether [REDACTED] txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

enp5s0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    ether [REDACTED] txqueuelen 1000 (Ethernet)
    RX packets 267706980 bytes 300970909734 (300.9 GB)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 3184 bytes 590575 (590.5 KB)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

When not using VLAN

2. Run this command in the terminal:

```
sudo ifconfig ${interface_name} ${ip_addr}
```

- Replace `${interface_name}` with the host computer's network interface name.
- Replace `${ip_addr}` with the host computer's IP address.

When using VLAN

2. Run this command in the terminal:

```
sudo ip link add link ${interface_name} name ${interface_name}.${vlan_id} type vlan id ${vlan_id}
sudo ip link set up ${interface_name}.${vlan_id}
sudo ip addr add ${ip_addr}/24 dev ${interface_name}.${vlan_id}
ip addr show ${interface_name}.${vlan_id}
```

- Replace `${interface_name}` with the host computer's network interface name.
- Replace `${vlan_id}` with the host computer's VLAN ID.
- Replace `${ip_addr}` with the host computer's IP address.


2.5. Tools

Tool	Purpose	Where to find it
PandarView 2	Point cloud visualization software: To record and display point cloud data.	Contact Hesai technical support to obtain it.
Pandar TCP Commands (PTC) API	To set parameters, check device info and status, or upgrade firmware and software. Network parameters: • Default Source IPv4 address: 192.168.1.201 • Default PTC port: 9347	Contact Hesai technical support to receive the API Reference Manuals.

3. Data structure

The lidar outputs Point Cloud Data Packets.

Unless otherwise specified, all the multi-byte fields are unsigned values in little-endian format.



1. Network monitoring software (such as WireShark) usually does not display the **Ethernet tail** (4 bytes).

Figure 19. Data structure

3.1. Point Cloud Data Packet

Before receiving Point Cloud Data Packets, please perform [Network settings on the host computer](#).

3.1.1. Ethernet Header

Point Cloud Data Packet: Ethernet Header

Field	Byte(s)	Description
Ethernet II MAC	12	Destination MAC: xx:xx:xx:xx:xx:xx (FF:FF:FF:FF:FF:FF for broadcast) Source MAC: xx:xx:xx:xx:xx:xx
Ethernet Data Packet Type	2	0x08, 0x00
Internet Protocol	20	Protocol parameters
UDP Port Number	4	Source port (default: 10000) Destination port (default: 2368)
UDP Length	2	Eight bytes more than point cloud UDP data (see Figure 19. Data structure).
UDP Checksum	2	Checksum of the Ethernet Header

3.1.2. UDP data

Pre-Header

Field	Byte(s)	Description
Start of Packet	1	0xEE
Start of Packet	1	0xFF
Protocol Version Major	1	Main class of the point cloud UDP packet structure Current value: 0x04
Protocol Version Minor	1	Subclass of the point cloud UDP packet structure Current value: 0x0A
Protocol Version Patch	1	Patch of the point cloud UDP packet structure Current value: 0x00
SW Version Major	1	Main class of the SW Version Current value: 0x00
SW Version Minor	1	Subclass of the SW Version Current value: 0x00
SW Version Patch	1	Patch of the SW Version Current value: 0x00
Reserved	2	-

Header

Field	Byte(s)	Description										
Channel Num	2	Number of channels Fixed: 0x012C (300)										
Block Num	1	Number of block(s) per packet Fixed: 0x01 (1)										
First Block Return	1	Indicating the return in the block of this packet. 0x01 — Dual Return mode: The first block stores the No. 1 return of this return mode. 0x02 — Dual Return mode: The first block stores the No. 2 return of this return mode. For example , if the First Block Return field is 0x02 and the Return Mode field is 0x3C (Dual Return – First and Strongest), then the first block in this packet stores the strongest return of a firing.										
Dis Unit	1	Unit of the Distance field in Section 3.1.2.3 Body . Fixed: 0x05 (5 mm)										
Return Num	1	Maximum number of returns from each channel Fixed: 0x02 (2)										
Flags	1	Each bit indicates whether this data packet contains certain information. 1 — YES 0 — NO <table><tr><th>Bit</th><th>Value</th></tr><tr><td>[7:4] Reserved</td><td>-</td></tr><tr><td>[3] Digital Signature</td><td>1</td></tr><tr><td>[2:1] Reserved</td><td>-</td></tr><tr><td>[0] UDP Sequence</td><td>1</td></tr></table>	Bit	Value	[7:4] Reserved	-	[3] Digital Signature	1	[2:1] Reserved	-	[0] UDP Sequence	1
Bit	Value											
[7:4] Reserved	-											
[3] Digital Signature	1											
[2:1] Reserved	-											
[0] UDP Sequence	1											

Body

Field	Byte(s)	Description
Azimuth	2	Low-resolution part of the encoder angle Unit: 0.01°  - Encoder angle is measured by the optical encoder and is used as the current reference azimuth of this block. - To convert from encoder angle to point cloud horizontal angle, refer to Section A.3 Angle correction calculation.
Fine Azimuth	1	High-resolution part of the encoder angle Unit: 0.01°/256 Encoder angle of the Block = Azimuth × 0.01° + Fine Azimuth × 0.01°/256
Block	900	Measurements made by each channel, starting from Enabled Channel 1 (see Each block in the Body).
CRC	4	CRC-32 checksum of the Body

Each block in the Body

Field	Byte(s)	Description												
Enabled Channel 1	3	Measurements of enabled channel 1												
		<table><tr><th>Field</th><th>Byte(s)</th><th>Description</th></tr><tr><td>Distance</td><td>2</td><td>Object distance = Distance × Dis Unit  Dis Unit is specified in Section 3.1.2.2 Header. </td></tr><tr><td rowspan="4">Confidence and Reflectivity</td><td rowspan="4">1</td><td>[7] Confidence level 0 — Normal 1 — Low confidence</td></tr><tr><td>[6] Reserved</td></tr><tr><td>[5:0] Reflectivity Range: 0 to 62 (0b111110) The mapping between this field and target reflectivity is detailed in Appendix B Nonlinear reflectivity mapping.</td></tr><tr><td></td></tr></table>	Field	Byte(s)	Description	Distance	2	Object distance = Distance × Dis Unit  Dis Unit is specified in Section 3.1.2.2 Header.	Confidence and Reflectivity	1	[7] Confidence level 0 — Normal 1 — Low confidence	[6] Reserved	[5:0] Reflectivity Range: 0 to 62 (0b111110) The mapping between this field and target reflectivity is detailed in Appendix B Nonlinear reflectivity mapping .	
		Field	Byte(s)	Description										
		Distance	2	Object distance = Distance × Dis Unit  Dis Unit is specified in Section 3.1.2.2 Header.										
		Confidence and Reflectivity	1	[7] Confidence level 0 — Normal 1 — Low confidence										
[6] Reserved														
[5:0] Reflectivity Range: 0 to 62 (0b111110) The mapping between this field and target reflectivity is detailed in Appendix B Nonlinear reflectivity mapping .														
Enabled Channel 2	3	Measurements of enabled channel 2												
...	...	...												
Enabled Channel 300	3	Measurements of enabled channel 300												

Tail

Field	Byte(s)	Description
Reserved	6	-
High Temperature Shutdown Flag	1	 This field is not yet supported.
ROI Start Channel	1	Channel number of the ROI's topmost channel Current value: 60 (indicating Channel 61)  Dynamic ROI is not yet supported.
Reserved	3	-
Frame Rolling Counter	1	Cycle counter of frames Range: 0 to 254 Increments by 1 at the end of each frame. Reset to 0 at every start-up.
Reserved	6	-
Motor Speed	2	Spin rate of the motor Unsigned integer Unit: 0.1 RPM Motor speed in RPM = Motor Speed × 0.1 - 3276.8  • By default, each of the 3 mirror surfaces corresponds to a point cloud frame. Thus, for every motor rotation, 3 frames are generated. • Spin rate of the motor (RPM) = frame rate (Hz) × 60 / 3
Timestamp Nanosec	4	The nanosecond part of the timestamp of this data packet Unit: ns Range: 0 to 999 999 999 ns (1 s)
Return Mode	1	0x3C — First and Strongest

Field	Byte(s)	Description
Factory Information	1	Fixed: 0x42
Timestamp Sec	4	Whole second part of the Coordinated Universal Time (UTC) of this data packet Format: number of seconds since the Unix epoch (1970-01-01 00:00:00 UTC)
Reserved	2	-
UDP Sequence	4	Sequence number of this UDP packet Range: 0 to 0xFF FF FF FF
CRC	4	CRC-32 checksum of the Tail

Cybersecurity

Field	Byte(s)	Description
Signature	32	Point cloud signature Calculated using point cloud UDP data (from Pre-Header to Tail) Algorithm: CMAC (128 bits) or HMAC-SHA256 (256 bits)  This field is not yet supported.
SQC	4	Sequence counter Current value: 0
CRC	4	Current value: 0

3.1.3. Ethernet tail

Field	Byte(s)	Description
FCS	4	Frame check sequence

3.1.4. Point cloud data analysis method

A software development kit (SDK) is available for analyzing point cloud data. Please contact Hesai technical support.

4. Maintenance

The lidar's optical window is made of plastic (polycarbonate, PC), similar to the material used for car lamps.

- Do NOT wipe the optical window when it is dry, nor use abrasive cleaners. Doing so can damage the optical coating.
- Do NOT use organic cleaners, which can damage the optical window and even cause cracking.
 - Organic cleaners include but are not limited to tar removers, self-cleaning agents, adhesive removers, coating removers, foam cleaners, iron powder removers for car paint, glass cleaners, thinning agents, de-icers, paint surface treatment agents, alcohol, and vinegar.
 - If organic cleaners may be present when cleaning the equipment or performing related operations, please protect the optical window to prevent any contact with organic cleaners.
- Do NOT apply excessive force to the lidar, as this can damage the optical window.
 - If a pressure washer is used to clean the optical window, make sure the distance between the nozzle and the optical window remains at least 60 cm.
 - Using automatic cleaning devices that are not specifically designed for lidars may pose risks. Please contact Hesai technical support for assessment.
 - Do NOT use sharp objects (such as knives or metal tweezers) or hard brushes (such as stiff nylon brushes or wire brushes) to scratch the optical window cover surface. Such actions may damage the optical window surface, and in severe cases, may cause malfunction.
- After prolonged exposure to strong sunlight and high temperatures, the optical window should NOT be cleaned immediately.
- If snow or ice accumulates on the optical window, do NOT use a pressure washer or ice scraper.
 - A small broom is recommended to remove snow.
 - A solvent-free (i.e., free of organic solvents) ice removal spray is recommended to remove ice; alternatively, wait for the ice to melt by itself.
- Do NOT wax the optical window.



Please regularly check on the optical window, considering your use frequency, storage environment, and climate conditions.



- If foreign objects (such as dust, fingerprints, or oil stains) are found on the optical window, make sure to clean them.
- If corrosive foreign objects (such as insect remains, bird droppings, tree resin, road dust, industrial dust, asphalt, soot particles, and road salt) are found on the optical window, make sure to clean them immediately.

Cleaning procedure

1. Make sure the lidar is powered OFF.
2. Choose an appropriate cleaning agent:
 - For light stains, use room temperature water.
 - For heavier stains, use a mild soap solution (no more than two tablespoons of soap per quart or liter of water).
 - For stubborn stains, use a solvent-free (i.e., free of organic solvents), pH-neutral detergent at room temperature, such as car shampoo.
3. Take a clean soft sponge or anti-static microfiber cloth, dampen it with the chosen cleaning agent, and gently wipe the dirty area on the optical window back and forth.
4. For stubborn stains, cover the dirty area with the dampened sponge or cloth to soften the stains before wiping.
5. Immediately after removing the stains, rinse the optical window with clean water. Then, use a clean soft sponge or microfiber cloth to gently wipe away any remaining liquid (which may contain residual cleaning agents or contaminants).

Appendix A: Channel distribution data

A.1. Angular position and performance

Notes to the table

Channel number	Counts from 1, top to bottom.
Angular position	The design values of each channel's horizontal (azimuth) angle offset and vertical (elevation) angle. • The accurate values are recorded in this lidar unit's angle correction file. • To analyze point cloud data, refer to Section 3.1.4 Point cloud data analysis method.
Enable	300 out of the 360 channels are enabled.

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
1	2.547°	8.975°	Yes
2	2.547°	8.925°	No
3	2.547°	8.875°	Yes
4	2.547°	8.825°	No
5	2.547°	8.775°	Yes
6	2.547°	8.725°	No
7	2.547°	8.675°	Yes
8	2.547°	8.625°	No
9	2.547°	8.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
10	2.547°	8.525°	No
11	2.547°	8.475°	Yes
12	2.547°	8.425°	No
13	2.547°	8.375°	Yes
14	2.547°	8.325°	No
15	2.547°	8.275°	Yes
16	2.547°	8.225°	No
17	2.547°	8.175°	Yes
18	2.547°	8.125°	No
19	2.547°	8.075°	Yes
20	2.547°	8.025°	No
21	2.547°	7.975°	Yes
22	2.547°	7.925°	No
23	2.547°	7.875°	Yes
24	2.906°	7.825°	No
25	2.906°	7.775°	Yes
26	2.906°	7.725°	No
27	2.906°	7.675°	Yes
28	2.906°	7.625°	No
29	2.906°	7.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
30	2.906°	7.525°	No
31	2.906°	7.475°	Yes
32	2.906°	7.425°	No
33	2.906°	7.375°	Yes
34	2.906°	7.325°	No
35	2.906°	7.275°	Yes
36	2.906°	7.225°	No
37	2.906°	7.175°	Yes
38	2.906°	7.125°	No
39	2.906°	7.075°	Yes
40	2.906°	7.025°	No
41	2.906°	6.975°	Yes
42	2.906°	6.925°	No
43	2.906°	6.875°	Yes
44	2.906°	6.825°	No
45	2.906°	6.775°	Yes
46	2.547°	6.725°	No
47	2.547°	6.675°	Yes
48	2.547°	6.625°	No
49	2.547°	6.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
50	2.547°	6.525°	No
51	2.547°	6.475°	Yes
52	2.547°	6.425°	No
53	2.547°	6.375°	Yes
54	2.547°	6.325°	No
55	2.547°	6.275°	Yes
56	2.547°	6.225°	No
57	2.547°	6.175°	Yes
58	2.547°	6.125°	No
59	2.547°	6.075°	Yes
60	2.547°	6.025°	No
61	2.547°	5.975°	Yes
62	2.547°	5.925°	Yes
63	2.547°	5.875°	Yes
64	2.547°	5.825°	Yes
65	2.547°	5.775°	Yes
66	2.547°	5.725°	Yes
67	2.547°	5.675°	Yes
68	2.547°	5.625°	Yes
69	2.906°	5.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
70	2.906°	5.525°	Yes
71	2.906°	5.475°	Yes
72	2.906°	5.425°	Yes
73	2.906°	5.375°	Yes
74	2.906°	5.325°	Yes
75	2.906°	5.275°	Yes
76	2.906°	5.225°	Yes
77	2.906°	5.175°	Yes
78	2.906°	5.125°	Yes
79	2.906°	5.075°	Yes
80	2.906°	5.025°	Yes
81	2.906°	4.975°	Yes
82	2.906°	4.925°	Yes
83	2.906°	4.875°	Yes
84	2.906°	4.825°	Yes
85	2.906°	4.775°	Yes
86	2.906°	4.725°	Yes
87	2.906°	4.675°	Yes
88	2.906°	4.625°	Yes
89	2.906°	4.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
90	2.906°	4.525°	Yes
91	2.547°	4.475°	Yes
92	2.547°	4.425°	Yes
93	2.547°	4.375°	Yes
94	2.547°	4.325°	Yes
95	2.547°	4.275°	Yes
96	2.547°	4.225°	Yes
97	2.547°	4.175°	Yes
98	2.547°	4.125°	Yes
99	2.547°	4.075°	Yes
100	2.547°	4.025°	Yes
101	2.547°	3.975°	Yes
102	2.547°	3.925°	Yes
103	2.547°	3.875°	Yes
104	2.547°	3.825°	Yes
105	2.547°	3.775°	Yes
106	2.547°	3.725°	Yes
107	2.547°	3.675°	Yes
108	2.547°	3.625°	Yes
109	2.547°	3.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
110	2.547°	3.525°	Yes
111	2.547°	3.475°	Yes
112	2.547°	3.425°	Yes
113	2.547°	3.375°	Yes
114	2.906°	3.325°	Yes
115	2.906°	3.275°	Yes
116	2.906°	3.225°	Yes
117	2.906°	3.175°	Yes
118	2.906°	3.125°	Yes
119	2.906°	3.075°	Yes
120	2.906°	3.025°	Yes
121	2.906°	2.975°	Yes
122	2.906°	2.925°	Yes
123	2.906°	2.875°	Yes
124	2.906°	2.825°	Yes
125	2.906°	2.775°	Yes
126	2.906°	2.725°	Yes
127	2.906°	2.675°	Yes
128	2.906°	2.625°	Yes
129	2.906°	2.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
130	2.906°	2.525°	Yes
131	2.906°	2.475°	Yes
132	2.906°	2.425°	Yes
133	2.906°	2.375°	Yes
134	2.906°	2.325°	Yes
135	2.906°	2.275°	Yes
136	2.547°	2.225°	Yes
137	2.547°	2.175°	Yes
138	2.547°	2.125°	Yes
139	2.547°	2.075°	Yes
140	2.547°	2.025°	Yes
141	2.547°	1.975°	Yes
142	2.547°	1.925°	Yes
143	2.547°	1.875°	Yes
144	2.547°	1.825°	Yes
145	2.547°	1.775°	Yes
146	2.547°	1.725°	Yes
147	2.547°	1.675°	Yes
148	2.547°	1.625°	Yes
149	2.547°	1.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
150	2.547°	1.525°	Yes
151	2.547°	1.475°	Yes
152	2.547°	1.425°	Yes
153	2.547°	1.375°	Yes
154	2.547°	1.325°	Yes
155	2.547°	1.275°	Yes
156	2.547°	1.225°	Yes
157	2.547°	1.175°	Yes
158	2.547°	1.125°	Yes
159	2.906°	1.075°	Yes
160	2.906°	1.025°	Yes
161	2.906°	0.975°	Yes
162	2.906°	0.925°	Yes
163	2.906°	0.875°	Yes
164	2.906°	0.825°	Yes
165	2.906°	0.775°	Yes
166	2.906°	0.725°	Yes
167	2.906°	0.675°	Yes
168	2.906°	0.625°	Yes
169	2.906°	0.575°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
170	2.906°	0.525°	Yes
171	2.906°	0.475°	Yes
172	2.906°	0.425°	Yes
173	2.906°	0.375°	Yes
174	2.906°	0.325°	Yes
175	2.906°	0.275°	Yes
176	2.906°	0.225°	Yes
177	2.906°	0.175°	Yes
178	2.906°	0.125°	Yes
179	2.906°	0.075°	Yes
180	2.906°	0.025°	Yes
181	-2.906°	-0.025°	Yes
182	-2.906°	-0.075°	Yes
183	-2.906°	-0.125°	Yes
184	-2.906°	-0.175°	Yes
185	-2.906°	-0.225°	Yes
186	-2.906°	-0.275°	Yes
187	-2.906°	-0.325°	Yes
188	-2.906°	-0.375°	Yes
189	-2.906°	-0.425°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
190	-2.906°	-0.475°	Yes
191	-2.906°	-0.525°	Yes
192	-2.906°	-0.575°	Yes
193	-2.906°	-0.625°	Yes
194	-2.906°	-0.675°	Yes
195	-2.906°	-0.725°	Yes
196	-2.906°	-0.775°	Yes
197	-2.906°	-0.825°	Yes
198	-2.906°	-0.875°	Yes
199	-2.906°	-0.925°	Yes
200	-2.906°	-0.975°	Yes
201	-2.906°	-1.025°	Yes
202	-2.906°	-1.075°	Yes
203	-2.906°	-1.125°	Yes
204	-2.547°	-1.175°	Yes
205	-2.547°	-1.225°	Yes
206	-2.547°	-1.275°	Yes
207	-2.547°	-1.325°	Yes
208	-2.547°	-1.375°	Yes
209	-2.547°	-1.425°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
210	-2.547°	-1.475°	Yes
211	-2.547°	-1.525°	Yes
212	-2.547°	-1.575°	Yes
213	-2.547°	-1.625°	Yes
214	-2.547°	-1.675°	Yes
215	-2.547°	-1.725°	Yes
216	-2.547°	-1.775°	Yes
217	-2.547°	-1.825°	Yes
218	-2.547°	-1.875°	Yes
219	-2.547°	-1.925°	Yes
220	-2.547°	-1.975°	Yes
221	-2.547°	-2.025°	Yes
222	-2.547°	-2.075°	Yes
223	-2.547°	-2.125°	Yes
224	-2.547°	-2.175°	Yes
225	-2.547°	-2.225°	Yes
226	-2.906°	-2.275°	Yes
227	-2.906°	-2.325°	Yes
228	-2.906°	-2.375°	Yes
229	-2.906°	-2.425°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
230	-2.906°	-2.475°	Yes
231	-2.906°	-2.525°	Yes
232	-2.906°	-2.575°	Yes
233	-2.906°	-2.625°	Yes
234	-2.906°	-2.675°	Yes
235	-2.906°	-2.725°	Yes
236	-2.906°	-2.775°	Yes
237	-2.906°	-2.825°	Yes
238	-2.906°	-2.875°	Yes
239	-2.906°	-2.925°	Yes
240	-2.906°	-2.975°	Yes
241	-2.906°	-3.025°	Yes
242	-2.906°	-3.075°	Yes
243	-2.906°	-3.125°	Yes
244	-2.906°	-3.175°	Yes
245	-2.906°	-3.225°	Yes
246	-2.906°	-3.275°	Yes
247	-2.906°	-3.325°	Yes
248	-2.906°	-3.375°	Yes
249	-2.547°	-3.425°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
250	-2.547°	-3.475°	Yes
251	-2.547°	-3.525°	Yes
252	-2.547°	-3.575°	Yes
253	-2.547°	-3.625°	Yes
254	-2.547°	-3.675°	Yes
255	-2.547°	-3.725°	Yes
256	-2.547°	-3.775°	Yes
257	-2.547°	-3.825°	Yes
258	-2.547°	-3.875°	Yes
259	-2.547°	-3.925°	Yes
260	-2.547°	-3.975°	Yes
261	-2.547°	-4.025°	Yes
262	-2.547°	-4.075°	Yes
263	-2.547°	-4.125°	Yes
264	-2.547°	-4.175°	Yes
265	-2.547°	-4.225°	Yes
266	-2.547°	-4.275°	Yes
267	-2.547°	-4.325°	Yes
268	-2.547°	-4.375°	Yes
269	-2.547°	-4.425°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
270	-2.547°	-4.475°	Yes
271	-2.906°	-4.525°	Yes
272	-2.906°	-4.575°	Yes
273	-2.906°	-4.625°	Yes
274	-2.906°	-4.675°	Yes
275	-2.906°	-4.725°	Yes
276	-2.906°	-4.775°	Yes
277	-2.906°	-4.825°	Yes
278	-2.906°	-4.875°	Yes
279	-2.906°	-4.925°	Yes
280	-2.906°	-4.975°	Yes
281	-2.906°	-5.025°	Yes
282	-2.906°	-5.075°	Yes
283	-2.906°	-5.125°	Yes
284	-2.906°	-5.175°	Yes
285	-2.906°	-5.225°	Yes
286	-2.906°	-5.275°	Yes
287	-2.906°	-5.325°	Yes
288	-2.906°	-5.375°	Yes
289	-2.906°	-5.425°	Yes

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
290	-2.906°	-5.475°	Yes
291	-2.906°	-5.525°	Yes
292	-2.906°	-5.575°	Yes
293	-2.906°	-5.625°	Yes
294	-2.547°	-5.675°	Yes
295	-2.547°	-5.725°	Yes
296	-2.547°	-5.775°	Yes
297	-2.547°	-5.825°	Yes
298	-2.547°	-5.875°	Yes
299	-2.547°	-5.925°	Yes
300	-2.547°	-5.975°	Yes
301	-2.547°	-6.025°	No
302	-2.547°	-6.075°	Yes
303	-2.547°	-6.125°	No
304	-2.547°	-6.175°	Yes
305	-2.547°	-6.225°	No
306	-2.547°	-6.275°	Yes
307	-2.547°	-6.325°	No
308	-2.547°	-6.375°	Yes
309	-2.547°	-6.425°	No

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
310	-2.547°	-6.475°	Yes
311	-2.547°	-6.525°	No
312	-2.547°	-6.575°	Yes
313	-2.547°	-6.625°	No
314	-2.547°	-6.675°	Yes
315	-2.547°	-6.725°	No
316	-2.906°	-6.775°	Yes
317	-2.906°	-6.825°	No
318	-2.906°	-6.875°	Yes
319	-2.906°	-6.925°	No
320	-2.906°	-6.975°	Yes
321	-2.906°	-7.025°	No
322	-2.906°	-7.075°	Yes
323	-2.906°	-7.125°	No
324	-2.906°	-7.175°	Yes
325	-2.906°	-7.225°	No
326	-2.906°	-7.275°	Yes
327	-2.906°	-7.325°	No
328	-2.906°	-7.375°	Yes
329	-2.906°	-7.425°	No

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
330	-2.906°	-7.475°	Yes
331	-2.906°	-7.525°	No
332	-2.906°	-7.575°	Yes
333	-2.906°	-7.625°	No
334	-2.906°	-7.675°	Yes
335	-2.906°	-7.725°	No
336	-2.906°	-7.775°	Yes
337	-2.906°	-7.825°	No
338	-2.906°	-7.875°	Yes
339	-2.547°	-7.925°	No
340	-2.547°	-7.975°	Yes
341	-2.547°	-8.025°	No
342	-2.547°	-8.075°	Yes
343	-2.547°	-8.125°	No
344	-2.547°	-8.175°	Yes
345	-2.547°	-8.225°	No
346	-2.547°	-8.275°	Yes
347	-2.547°	-8.325°	No
348	-2.547°	-8.375°	Yes
349	-2.547°	-8.425°	No

Channel number	Angular position		Enabled?
	Horizontal angle offset (azimuth)	Vertical angle (elevation)	
350	-2.547°	-8.475°	Yes
351	-2.547°	-8.525°	No
352	-2.547°	-8.575°	Yes
353	-2.547°	-8.625°	No
354	-2.547°	-8.675°	Yes
355	-2.547°	-8.725°	No
356	-2.547°	-8.775°	Yes
357	-2.547°	-8.825°	No
358	-2.547°	-8.875°	Yes
359	-2.547°	-8.925°	No
360	-2.547°	-8.975°	Yes

A.2. Angle correction file

Purpose

- For analyzing point cloud data
- For accurately displaying point cloud in PandarView 2

How to obtain it (using one of these ways)

- Send PTC command 0x05; see the TCP API Reference Manual.
- Export the file using PandarView 2; see the PandarView 2 User Manual.
- Ask Hesai technical support or your sales representative.

Data format

See table below.



- To view the .dat file, use a hex viewer to open it.
- Byte size of the file: $32 + 8 \times M + (8 + 1) \times N + 180 \times 2 \times V = 9056$
- Unless otherwise specified, all the multi-byte fields are in little-endian format.

Field	Byte(s)	Type	Description
Beginning of File	1	uint	0xEE
Beginning of File	1	uint	0xFF
Protocol Version Major	1	uint	Main class of the angle correction data structure Current value: 0x01
Protocol Version Minor	1	uint	Subclass of the angle correction data structure Current value: 0x09
File Length	2	uint	Current value: 0x23 60 (9056 bytes)
Channel Number	2	uint	Number of channels N Fixed: 0x01 68 (360)

Field	Byte(s)	Type	Description
Laser Number	1	uint	Fixed: 0x10 (16)
Mirror Number	1	uint	Mirror number M Fixed: 0x03 (3 mirror surfaces)
Frame Number	1	uint	Frame number F for every 360° rotation Default: 0x03 (3 frames; each mirror surface corresponds to one frame)  This field is only used for PandarView 2 display configuration, not for point cloud data analysis.
Frame Config Byte	8	uint 8 array	The first F bytes represent the configuration of F frames, with one byte per frame; the other bytes are not used. Each byte is a bitmap: The first M bits correspond to M mirror surfaces; the other bits are not used. If a bit is set to 1, the measurements from the corresponding mirror surface are output to the byte's corresponding frame; otherwise, the measurements from that mirror surface are not output. See Examples of the Frame Config Byte .  This field is only used for PandarView 2 display configuration, not for point cloud data analysis.
Angle_Division	2	uint	Used in the units of the fields below. Always 0x64 00 (25600)
Mirror_Start_Angle[0:M-1]	12 (4 × M)	uint32 array	The encoder angle of each mirror surface's starting side Unit: (1/ Angle_Division)°

Field	Byte(s)	Type	Description
Mirror_End_Angle[0:M-1]	12 (4 × M)	uint32 array	The encoder angle of each mirror surface's ending side Unit: (1/Angle_Division)°  The range of each mirror surface (Mirror_End_Angle – Mirror_Start_Angle) ≈ 80°
Channel_Laser_Map[0:N-1]	360 (1 × N)	uint8 array	Mapping of each channel to one of the 16 lasers, one byte per channel. E.g., if Channel_Laser_Map[199] = 8, then Channel 200 corresponds to Laser 8.  Channel number starts from 1.
Azimuth_Offset[0:N-1]	1440 (4 × N)	int32 array	Each channel's horizontal angle offset, irrelevant to mirror rotation Unit: (1/Angle_Division)°
Elevation[0:N-1]	1440 (4 × N)	int32 array	Each channel's vertical angle offset, irrelevant to mirror rotation Unit: (1/Angle_Division)°
Reserved	1	-	-
Angle_Adjust_Division	2	uint	Used in the units of the fields below. Always 0x64 00 (25600)

Field	Byte(s)	Type	Description
Azimuth_Adjust[0:2880-1]	2880 ($V \times 180$)	int8 array	Each channel's horizontal angle adjustments for every 2° encoder angle, relevant to mirror rotation Format: 2D array[16][180] - The 16 rows correspond to Lasers 0 to 15. - The 180 columns correspond to encoder angle positions 0°, 2°, 4°, ..., and 358°. Unit: $(1/\text{Angle_Adjust_Division})^\circ$ E.g., if Channel_Laser_Map[199] = 8, then the horizontal angle adjustment of Channel 200 at the 180° encoder angle position is Azimuth_Adjust[8][90].  Channel number starts from 1.
Elevation_Adjust[0:2880-1]	2880 ($V \times 180$)	int8 array	Each channel's vertical angle adjustments for every 2° encoder angle, relevant to mirror rotation Format: 2D array[16][180] - The 16 rows correspond to Lasers 0 to 15. - The 180 columns correspond to encoder angle positions 0°, 2°, 4°, ..., and 358°. Unit: $(1/\text{Angle_Adjust_Division})^\circ$
CRC	8	uint	CRC64 checksum of this angle correction file

Examples of the Frame Config Byte

Frame number F	First F bytes of Frame Config Byte	Description
F = 3	0000 0001, 0000 0010, 0000 0100	• The measurements from Mirror Surfaces 0/1/2 are output to Frames 0/1/2, respectively. • The frames are not stitched.
F = 1	0000 0111	• The measurements from Mirror Surfaces 0/1/2 are output to one frame. • Every three frames are stitched as one. • The frame rate is 1/3 of that in the previous case, while the data points per frame are three times that of the previous case.
F = 1	0000 0000	• The measurements from Mirror Surfaces 0/1/2 are output to one frame according to their encoder angles in Point Cloud Data Packets. • No angle correction is performed.

A.3. Angle correction calculation

A.3.1. Horizontal angle of the current firing channel

$$h_{angle} = \left(\frac{\alpha}{100} + \frac{\alpha_{fine}}{25600} - \frac{Mirror_Start_Angle(frame_id)}{25600} \right) \times 2 - \frac{\alpha_{offset}(channel_id)}{Angle_Division} + \frac{\alpha_{adjust}(channel_id, azimuth_id)}{Adjust_Angle_Division}$$

Encoder angle of each mirror surface's starting side (Mirror_Start_Angle)	See angle correction file.
Each channel's horizontal angle offset (α_{offset})	See angle correction file.
Each channel's horizontal angle adjustments for every 2° encoder angle (α_{adjust})	See angle correction file.
Unit: (resolution)	See angle correction file.
Encoder angle of the current data block (low-resolution part α and high-resolution part α_{fine})	See Azimuth and Fine Azimuth in Section 3.1.2.3 Body .

A.3.2. Vertical angle of the current firing channel

$$v_{angle} = \frac{\varepsilon(channel_id)}{Angle_Division} + \frac{\varepsilon_{adjust}(channel_id, azimuth_id)}{Angle_Adjust_Division}$$

Each channel's vertical angle (ε)	See angle correction file.
Each channel's vertical angle adjustments for every 2° encoder angle (ε_{adjust})	See angle correction file.



If the encoder angle (α) is not divisible by 2°, the horizontal angle adjustments (α_{adjust}) and vertical angle adjustments (ε_{adjust}) should be linearly interpolated. For example:

- If the α_{adjust} for 50° and 52° encoder angles are a and b, respectively, then at the 51° encoder angle position, $\alpha_{adjust} = (a + b)/2$.
- If the ε_{adjust} for 50° and 52° encoder angles are c and d, respectively, then at the 50.5° encoder angle position, $\varepsilon_{adjust} = (3c + d)/4$.

Appendix B: Nonlinear reflectivity mapping

Alternatively, users may choose the Nonlinear Mapping mode using PTC commands.

This mapping increases the contrast in the low-reflectivity region.




Figure 20. Nonlinear mapping

Nonlinear mapping

Reflectivity field	Actual reflectivity (%)	Reflectivity field	Actual reflectivity (%)
0	0	32	67
1	2	33	70

Reflectivity field	Actual reflectivity (%)	Reflectivity field	Actual reflectivity (%)
2	4	34	73
3	6	35	76
4	8	36	79
5	10	37	82
6	12	38	85
7	14	39	88
8	16	40	91
9	18	41	94
10	20	42	97
11	22	43	100
12	24	44	103
13	26	45	106
14	28	46	109
15	30	47	112
16	32	48	115
17	34	49	118
18	36	50	121
19	38	51	124
20	40	52	127
21	42	53	130
22	44	54	133

Reflectivity field	Actual reflectivity (%)	Reflectivity field	Actual reflectivity (%)
23	46	55	136
24	48	56	139
25	50	57	142
26	52	58	145
27	54	59	172
28	56	60	199
29	58	61	226
30	61	62	254
31	64	63	N/A

Appendix C: Legal notice

Copyright © 2017-2025 Hesai Technology Co., Ltd.

All rights reserved. Use or reproduction of this manual in parts or in its entirety without the authorization of Hesai is prohibited.

Hesai Technology makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability, or fitness for any particular purpose. Further, Hesai Technology reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revisions or changes.

HESAI and HESAI logo are registered trademarks of Hesai Technology. All other trademarks, service marks, and company names in this manual or on Hesai's official website are properties of their respective owners.

The software included in this product contains the copyright that is registered under Hesai Technology. Any third party is not permitted, except as expressly permitted by the licensor or expressly required by applicable law, to decompile, reverse engineer, disassemble, modify, rent, lease, loan, distribute, sublicense, create derivative works based on the whole or any part of the software.

Hesai Product Warranty Service Manual is on the Warranty Policy page of Hesai's official website: <https://www.hesaitech.com/warranty-policy/>

Hesai Technology Co., Ltd.

Phone: +86 400 805 1233

Website: www.hesaitech.com

Address: Building A, Haisu Culture Plaza, Shanghai, China

Business Email: info@hesaitech.comService

Email: service@hesaitech.com