


X8-120 Interface Description




X8-120 Packaging Information



List:

- A. Power Supply + CAN BUS Communication Cable *2
- B. 120Ω Terminal Resistance *1
- C. EtherCAT Communication Cable *2
- D. CAN BUS Communication Module *1 (For each order, there will be a free USB-CAN adapter. If need more, please contact sales to buy.)

X8-120 Accessories Marking Instructions




A

Power Supply + CAN BUS Communication Cable


① XT30(2+2) Connector

② White Line :	CAN_L Network Signal Terminal
③ Yellow Line :	CAN_H Network Signal Terminal
④ Red Line :	VCC Positive Power Supply
⑤ Black Line :	GND Negative Power Supply



B

120Ω Terminal Resistance




C

EtherCAT Communication Cable

① SH1.0mm(4pin) Connector

② T	EtherCAT Communication Signal Transmission Line
③ R	EtherCAT Communication Signal Receiving Line



D

CAN BUS Communication Module

① CAN-L	CAN_L Network Information Terminal
② CAN-H	CAN_H Network Information Terminal
③ CAN-G	GND Ground
④ OFF	120Ω Terminal Resistance
⑤ ON	120Ω Terminal Resistance

Notes: For each order, there will be a free USB-CAN adapter. If need more, please contact sales to buy.